

Operating Instructions for: Germania

Germania is a Treble Booster providing up to 20db of gain. **The Germania** sounds best when ran thru the input of a tube amp. Never run the Germania thru an effects loop. Extreme temperatures can affect the performance of the pedal.

Gain control-Varies the amount of gain and treble boost. (Note: It is normal for the gain control to make a “scratchy” noise when turned.)

Input-Instrument in. Unplug when not in use to conserve battery life.

Out-Out to Amp

+9VDC jack-for use with +(positive) center 9VDC, filtered and regulated power supply.

On/Off- True bypass of effect. (Note: A small pop may occur when effect is switched on/off. This is normal and is a trait associated with true bypass.)

Hi/Low Fi Switch- Switches between a stock treble boost sound and a more open, brighter sound. (Note: Only switch the Hi/Low Fi switch with Gain knob down or pedal off! A loud pop will occur if switched with pedal on and gain up.)